

## Installing the Debris Deflector (PT 9050)



To mount the debris deflector (PT 9050) prick punch a hole  $1 \frac{1}{8}$  " down from the bottom of the throw plate and  $\frac{3}{4}$  " from the right side of the angle iron. Drill pilot hole using a  $\frac{1}{8}$  " drill bit; complete the hole with a  $\frac{1}{4}$  " drill bit.



Install the bracket using a shim between the top of the pulley wheel and bracket. A machinist ruler is shown but you can use a piece of cardboard from a shotgun shell box (.050"). The washer and nut need to go on the back side so that the washer covers the slot on the deflector. Once the bolt is secured remove the shim.

